



SERVICE PARTS LIST

BULLETIN NO.
54-06-0020

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS			REVISED BULLETIN	DATE
M18™ LED HP FLOOD LIGHT				May 2018
CATALOG NO.	2360-20	STARTING SERIAL NO.	WIRING INSTRUCTION	
		H02A		


EXAMPLE:

00	0
----	---

 Component Parts (Small #)
 Are Included When Ordering
 The Assembly (Large #).

NOTE:
 Model 2360-20 M18™ LED Floodlight (Serial Break 'A') is designed to operate off of several different M18 REDLITHIUM™ battery sizes from 1.5 amp-hours to 9.0 amp-hours.

To power a 2360-20 M18™ LED Floodlight (serial break 'A') with a 48-11-1812 M18™ REDLITHIUM™ 12.0 amp-hour battery, 12.0 Upgrade Service Kit 14-46-0086 must be ordered to accommodate the larger size battery.



NOTE: Hand tighten all fasteners. Use of power tools could strip fasteners or damage housings.

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	44-06-0120	Lens Kit	(1)
2	-----	M3 x 8mm Pan Hd. T-10 Screw	(4)
3	-----	Lens w/ cover	(1)
4	43-76-0020	Lamp Housing Kit	(1)
5	-----	M3 x 8mm Pan Hd. Philips Machine Screw	(4)
6	-----	M4 x 16mm Pan Hd. T-20 Screw	(4)
7	23-36-0020	Plug w/ wires	(1)
8	12-20-2001	Service Nameplate (not shown)	(1)

FIG. NOTES

7 When replacing the plug, wires must be carefully unsoldered from the circuit board. Replacement plug wires are to be soldered in the placement shown (see picture). Apply the solder from the back.

8 A clean, dry surface is essential for proper performance for any adhesive system. The area intended for application of any adhesive label or nameplate must be prepared by cleaning with isopropyl alcohol. The solvent is to be applied with a clean, lint free applicator and the surface allowed to dry before applying the label or nameplate.